

L'original

DRAGONFLY FAN



Fonctionnement: Pour fonctionner, renversez le commutateur vers le haut (position 1) pour dessus et vers le bas pour au loin. Assurez-vous que rien n'obstrue la pale de ventilateur pour éviter tout blocage.

Entretien

Important: Evitez un blocage prolongé de la pale de ventilateur. Dans des conditions extrêmes, la pale risque de s'endommager à l'endroit où elle est attachée à l'arbre. Si des dommages se produisent, la pale ne sera pas bien retenue sur l'arbre et on devrait la remplacer par une pale neuve.

Lire et conserver ces directives

Advertissment- Pour réduire les risques d'incendie ou de chocs électriques, ne pas utiliser ce produit avec un appareil régulateur de vitesse transistorisé (commutateur de gradateur de lumière).

- ✦ Débranchez le ventilateur avant de le nettoyer.
- ✦ Faites preuve de bon sens lorsque vous utilisez cet appareil ou tout autre appareil électrique.
- ✦ Ne placez pas l'appareil trop près d'objets qui pourraient être attirés dans les pales et arrêter ainsi la circulation d'air.
- ✦ Ne l'utilisez pas à l'extérieur.
- ✦ Ne l'utilisez pas sur des surfaces mouillées et ne le submergez pas dans l'eau. Ne laissez jamais de l'eau dégoutter dans le carter du moteur.
- ✦ N'utilisez pas l'appareil si le cordon d'alimentation électrique s'effiloche ou devient cassant.
- ✦ N'utilisez pas de gaz, de solvants ou d'autres produits chimiques durs pour nettoyer le ventilateur.
- ✦ N'utilisez pas près des foyers, fournaies, cuisinières ou d'autres sources de chaleur à haute température.

Mise en garde: à garder hors de la portée des enfants.

Fiche technique

- ✦ 120volts, 60Hz, 0.15 Ampere
- ✦ Cordon d'alimentation de 2.4 m (6pi)

Garantie

- ✦ Limitée d'un an garantie



303PK-011.REV1.0

The Original

DRAGONFLY FAN



Operation: To operate, flip the switch up (position 1) for on and down for off. The blade must be clear of any obstructions that would cause the blade to jam.

Care and Maintenance

Important: Avoid prolonged jamming of the fan blade. Under extreme conditions damage can occur to the blade at the point where it attaches to the shaft. If damaged, the blade will not be secure on the shaft and will have to be replaced with a new blade.

Read and Save these instructions

Warning: To reduce the risk of fire or shock, do not use this product with any solid-state speed control device (Dimmer switch).

- ✦ Unplug fan before cleaning
- ✦ Use common sense when using this and/or any electrical appliance
- ✦ Do not position too close to any objects which may be drawn into the blades and stop the air flow.
- ✦ Do not use outdoors.
- ✦ Do not use on wet surfaces or immerse in water. Never allow water to drip into motor housing.
- ✦ Do not use if power supply cord becomes frayed or brittle.
- ✦ Do not use gasoline, thinners or other harsh chemicals to clean fan.
- ✦ Do not use near fireplaces, furnaces, stoves or high temperature heat.
- ✦ It is normal for the fan body to become warm during operation.

Caution: Keep out of the reach of children

Specifications

- ✦ 120 volts, 60Hz, 0.15 Amp.
- ✦ 6ft.cord

Warranty

- ✦ Limited 1 year warranty



303PK-011.REV1.0