

Canada & Netherlands: European market debut for Caframo Kona at METS

Thursday, 12 November 2009

Marine fan manufacturer Caframo will introduce the new and improved design of its best-selling Kona to the European marine market at METS (Marine Equipment Trade Show) 2009, November 17-19 in Amsterdam (Stand 11.212 at the RAI). The powerful but low-draw weatherproof fan is specially designed for exterior use in the most demanding marine conditions and is ideal for sailboats and other smaller battery capacity vessels.

Featuring a watertight motor and constructed of extruded aluminum, UV stabilized plastic and stainless fasteners, the new Kona 817 is ideal for the wheelhouse, dash, an exposed bridge or cockpit where splash and spray would spell disaster for other fans.

Designed and tested with the latest in 3D parametric and computational fluid dynamic software for maximum airflow and efficiency, the blade and grill of the IP55 (Ingress Protection against dust and spray) rated Kona 817 combine to deliver an airflow rating of 266CFM on high speed. But the battery-friendly 3 speed fan draws only 0.21 amps on low, 0.26 on medium, and 0.37 on high.

Two mounting options for the Kona 817 are available. A screw-down base for a permanent, secure mount ensures it stays in place in rough seas. There is also a strong, reliable cam-lock suction mount for a more portable application, providing the user with versatility in its uses allowing for airflow both on and below deck. Available in white or black, 12 or 24-volts.

Last Updated (Thursday, 12 November 2009)